

University of Texas Electronic Music Studios  
**EMS-III TRANSFERRING FROM MINIDISC**

- 1) The Sony MiniDisc unit is connected to the 2TR -D2 input of the Yamaha 02R.
- 2) On page 1 of the "DIGITAL I/O" setup change the clock source to "2TR D2".
- 3) On the 2nd page of the "DIGITAL I/O" setup make sure that "LINE 19/20" is set to "2TR-IN D2". This patches the digital input to the fader corresponding with 19/20.
- 4) In the "ROUTING" configuration screen, assign busses 1 and 2 to stereo channel 19/20. This is how the signal will be sent to the audio interfaces.
- 5) You might want to disable the routing of stereo channel 19/20 to the stereo bus. This way you can monitor the signal that is being recording, rather than the signal going to the board.
- 6) Record from the first two digital inputs in your audio software.